

TBM Racing SX-R 800 Super Scoop™

Congratulations on your purchase of the TBM Racing Super Scoop™, the first intake grate designed exclusively for the SX-R 800. This is not a revised 750 SXI intake, it's designed to enhance the handling characteristics of the 800 and correct its one inefficiency, which is keeping the pump hooked up in hard corners. The Super Scoop™ keeps the pump loaded when the ski is on edge as is the case in fast hard cornering. We also treat each grate with a corrosion resistant coating rather than the typical (cheaper) ball burnished finish that quickly corrodes when exposed to salt water. We are proud to bring you a truly "race ready" part that doesn't need modification to be worthy of Pro level racing. Follow the simple installation instructions below and say goodbye to the competition!

Installation instructions

1. Remove your existing intake grate.
2. Clean grease, sand, and residue from the pump shoe and front hull inserts.
3. Apply a bead of silicone to the face of the pump shoe and two front hull inserts where it will mate with the Super Scoop™.
4. Apply a drop of blue loctite to O.E.M. hardware and install the Super Scoop™ at this time.
5. Torque the four mounting bolts to the manufacturer's specifications.
6. Allow silicone to cure for 24hrs and you're ready to ride.